

## E.COLI/COLIFORM (10 TESTS)

Product group: **661** Product number: **500002**

The most basic test for bacterial contamination of a water supply is the test for total coliform bacteria. Total coliform counts give a general indication of the sanitary condition of a water supply.



For consistent results, an incubator should be used to culture the samples and the correct temperature.

(UV lamp supplied separately)

### Product information

Test Parameters: Coliform and E Coli bacteria tests Qty: 10 tests

Supplied with box containing pack of 10 Coli test bags and 10 ampules of growth media

Used with:

POTABLE WATER TEST KIT (778419)  
BALLAST CHECK 2 TEST KIT (777848)  
PORTABLE INCUBATOR (777930)  
UV LAMP (777931)

### Features

- Simple presence/absence test
- Easy to carry out on board ship
- Can be to test for Potable water and ballast water For Ballast water, dilute the sample by 1 part sample and 9 part deionised water (10 ml sample + 90 ml demin water = 100 ml sample)

### Benefits

- Convenient method for measuring and monitoring bacteria and microbial activity in water,
- High quality and consistently reliable results

### Documents

[SDoC and MD for IHM](#)

### Related products

Is accessory to

**777619**  
POTABLE WATER TEST KIT W/O E.COLI

This page is printed from

<https://wilhelmsenstage.wilhelmsen.com/product-catalogue/products/e.colicoliform-10-tests>